


VT8000 Series Firmware Upgrade

Firmware Upgrade Procedure



Introduction

This procedure shows you how to upload a Firmware file to the VT8000 Series Room Controllers.

The VT8000 Uploader Tool can be installed on Computers and Tablets running the following operating systems:

- Microsoft Windows 7, 32-bit (requires Service Pack 1 and .NET framework 4.5).
- Microsoft Windows 7, 64-bit.
- Microsoft Windows 8, 32-bit and 64-bit

INSTALL UPLOADER TOOL


1. Download Uploader Tool from www.viconics.com
2. Download latest Firmware file from www.viconics.com

COPY FIRMWARE FILE TO LOCAL DRIVE

1. Download necessary Firmware file to Desktop.
2. Navigate to C:\Uploader8000 folder.
3. Copy and paste Firmware file into Uploader8000 folder.
NOTE: Ensure to overwrite the existing file with the new file.

CONNECT TO VT8000 SERIES ROOM CONTROLLER

This procedure requires the use of a Micro-USB (B-type) to USB (A-type) cable.



UPGRADE FIRMWARE

1. Connect A-type plug to PC and connect B-type plug to VT8000 Room Controller.
2. Click desktop short-cut to activate Uploader Tool.
3. Toggle **Advanced Mode**.
4. Toggle **Firmware** and **Fonts library**.
5. Select Firmware file available in drop-down menu.
6. Click **Upload** and wait for operation to complete successfully.
NOTE: do not shut down Uploader tool or disconnect USB cable during this step until operation is complete.
7. Close Uploader Tool.

